


## Speakerphone with 12-Number Memory User's Guide

### INTRODUCTION

Your speakerphone is designed to give you flexibility in use and high quality performance. To get the most from your new telephone, we suggest that you take a few minutes right now to read through this instruction manual.




**WARNING:** TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

### BEFORE YOU BEGIN

#### PARTS CHECKLIST

Your package should contain the following items:




Base unit Handset Handset cord Phone line cord

#### MODULAR JACK


#### REQUIREMENTS

You need an RJ14C or RJ11 type modular jack, which is the most common type of phone jack and might look like the one pictured here. If you don't have a modular jack, call your local phone company to find out how to get one installed.



### INSTALLATION

#### DESKTOP INSTALLATION



- Plug the handset cord into the handset, and into the telephone jack on the left side of the unit.
- Plug the telephone line cord into a modular jack (RJ11C or RJ14C) and into the PHONE LINE jack on the back of the unit.
- Adjust the RINGER volume switch to the desired setting.
- Set the PULSE/TONE switch to TONE if you use Touch-Tone service; set it to PULSE if you have rotary service.
- The unit is properly installed if you pick up the handset and hear the dial tone. Otherwise, recheck all the installation steps.


#### PHONE CORD WRAP

You can wrap any extra phone cord to get it out of the way.


#### WALL MOUNT INSTALLATION

The speakerphone can be mounted on a wall phone plate (not included).

- Plug the phone cord into the phone jack on the back of the unit, and wrap the extra phone line around the bottom of the base.
- Connect the phone line to the modular jack on the wall.
- Slip the mounting holes over the wall plate posts and slide the unit down firmly into place.



- Plug the handset line into the unit, then hang up the phone.
- Set the PULSE/TONE switch to TONE if you use Touch-Tone service; set it to PULSE if you have rotary service.
- Set the RINGER VOLUME switch as desired.
- The unit is properly installed if you pick up the handset and hear the dial tone. Otherwise, recheck all installation steps.



### SPEAKERPHONE BASICS

#### SPEAKERPHONE LOCATION

For best speakerphone performance, avoid the following:

- Areas with high background noise. (The microphone might pick up these sounds and prevent the speakerphone from going into the receiving mode when you finish talking.)
- Surfaces affected by vibration.
- Recessed areas such as in a corner, under a cupboard, or next to a cabinet, which can generate an echo effect.

#### SPEAKERPHONE USE

Note the following guidelines when using the speakerphone:

- The speakerphone works similar to a two-way radio in that you can only listen or talk at one time.
- Stay reasonably close to the phone so that you can be clearly heard by the person to whom you are talking.
- You can adjust the speaker volume by sliding the VOLUME control on the right side of the base unit.
- The speakerphone indicator comes on when the speakerphone is in use.

#### MAKING A CALL

- Press the SPEAKER button instead of picking up the handset.
- Adjust volume if needed.
- Make your call.
- Press SPEAKER again to hang up the phone.

#### RECEIVING A CALL

Make sure that the RINGER switch is set to HI or LO or the phone will not ring.

- Press the SPEAKER button instead of picking up the handset when the phone rings.
- Adjust volume if needed.
- Press SPEAKER again to hang up the phone.

#### SWITCHING BETWEEN SPEAKER AND HANDSET


You can switch between speakerphone and handset while the phone is dialing a number, or anytime during a conversation.

- Speaker to Handset — Pick up the handset.
- Handset to Speaker — Press SPEAKER, then hang up handset.

### TELEPHONE BASICS

#### EMERGENCY QUICK DIAL buttons

#### STORE button



### VOLUME CONTROLS

Control the volume of both the handset and the speakerphone:

- Use the SPEAKER volume control to adjust speakerphone volume.
- Use the HANDSET RECEIVER volume control to adjust the handset volume.

### TEMPORARY TONE FEATURE

If you have Pulse (rotary) service, and want to access customer calling services that require Tone dialing, such as getting information from a local bank, you can use this feature.

- Press the tone button ( \* ) after you have connected to the service to enable Tone dialing.
- When you hang up, the phone automatically returns to Pulse dialing mode.

### FLASH

Press the FLASH button instead of using the hook switch to activate customer calling services such as call waiting or call transfer, which are provided by your local phone company.

### REDIAL

Redial the last number you called by pressing the REDIAL button after you get a dial tone.

**NOTE:** The Redial feature holds in memory the last phone number you dialed (as many as 31 digits). If you pressed any numbers after dialing the phone number, (for example, when accessing a voice-menu system) those numbers also are redialed.

### MEMORY

Store as many as 12 numbers in memory for easy dialing. Three can be stored in the Emergency Quick Dial locations, and nine additional numbers can be stored in the numbered keys (1-9).

### STORING A NUMBER IN MEMORY

- Press SPEAKER (or pick up the handset).
- Press STORE.
- Dial the number to be stored (up to 16 digits).
- Press STORE button.
- Press a Memory Location (1-9 on the keypad), or an EMERGENCY QUICK DIAL button.
- Press SPEAKER (or hang up the handset).
- Record the phone number on the memory directory (located under the plastic cover).

### ADDING A PAUSE TO THE DIALING SEQUENCE

Use the REDIAL button to insert a delay in the dialing sequence when storing a number, for example, when you need to dial 9 to get an outside line.

Press REDIAL at the point in the dialing sequence in which a pause is required.

### CHANGING A STORED NUMBER

Change a stored number by replacing it with a different number.

### DIALING A NUMBER FROM MEMORY

You can dial numbers from memory when using the handset or speakerphone. When you get a dial tone, press the MEMORY DIAL button followed by the memory location (1-9) for the number you want to dial.

**IMPORTANT:** If you make test calls to emergency numbers, remain on the line and explain the reason for the call. Also, make these calls in off-peak hours, such as early morning or late evening.

### DIALING THE EMERGENCY QUICK DIAL

#### NUMBERS

To dial one of these numbers, just press its button after you get a dial tone.

### CHAIN DIALING FROM MEMORY

Use this feature to make calls which require a sequence of numbers, for instance if you use a calling card for a frequently called long distance number. Basically, you dial each part of the sequence from memory. The following example shows how you can use chain dialing to make a call through a long distance service:

The Number For	Memory Location
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

- Press SPEAKER (or pick up the handset).
- Press the MEMORY DIAL button and then press 7.
- When you hear the access tone, press MEMORY DIAL and then press 8.
- At the next access tone, press MEMORY DIAL and then 9.

### TROUBLESHOOTING GUIDE

Problem	Solution
No dial tone. Won't dial out	<ul style="list-style-type: none"> <li>Check hook switch to make sure it pops up.</li> <li>Make sure speakerphone indicator comes on (if using speakerphone.)</li> <li>Make sure TONE/PULSE is set to correct position.</li> <li>Unplug the phone, wait 30 seconds, and plug the phone back in. Then lift the handset to check the dial tone.</li> </ul>
Phone doesn't ring	<ul style="list-style-type: none"> <li>Check RINGER volume.</li> <li>Could have too many phones on one line. (The total REN of all phones should not be greater than the maximum REN for your calling area, Usually 5.)</li> </ul>
Low handset or speaker volume	<ul style="list-style-type: none"> <li>Check the volume settings.</li> </ul>
Light and tone feedback flutter when dialing in PULSE mode.	<ul style="list-style-type: none"> <li>This is normal as power is fluctuating with phone outpulsing.</li> </ul>
Can't be heard by other party	<ul style="list-style-type: none"> <li>Make sure phone cord is securely plugged in.</li> </ul>
Memory dialing	<ul style="list-style-type: none"> <li>Make sure you entered numbers correctly. (See "Memory.")</li> </ul>

### GENERAL PRODUCT CARE

To keep your telephone working and looking good, follow these guidelines:

- Avoid putting it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Avoid dropping and other rough treatment to the answerer.
- Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the finish.
- Retain the original packaging in case you need to ship it at a later date.

### SERVICE

FCC requires this product to be serviced only by the manufacturer or its authorized service agents. In accordance with FCC requirements, changes or modifications not expressly approved by ATLINKS USA could void the user's authority to operate this product. For instructions on how to obtain service, call Consumer Information, **1-800-448-0329**.

Attach your sales receipt to the booklet for future reference or jot down the date this product was purchased or received as a gift. This information will be valuable if service should be required during the warranty period.

Purchase date \_\_\_\_\_

Name of store \_\_\_\_\_

### LIMITED WARRANTY

#### What your warranty covers:

- Any defect in materials or workmanship.

#### For how long after your purchase:

- One year.

(The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.)

#### What we will do:

- Provide you with a new or, at our option, a refurbished unit.

- The exchange unit is under warranty for the remainder of the original product's warranty period.

#### How to make a warranty claim:

- Properly pack your unit. Include any cables, etc., which were originally provided with the product. We recommend using the original carton and packing materials.

- Include evidence of purchase date such as the bill of sale. Also print your name and address and a description of the defect. Send via standard UPS or its equivalent to:

**Thomson Consumer Electronics, Inc.**  
11721 B Alameda Ave.  
Socorro, Texas 79927

- Pay any charges billed to you by the Exchange Center for service not covered by the warranty.

- Insure your shipment for loss or damage. Thomson accepts no liability in case of damage or loss en route to Thomson.

- A new or refurbished unit will be shipped to you freight prepaid.

#### What your warranty does not cover:

- Customer instruction. (Your Owner's Manual provides information regarding operating instructions and user controls. For additional information, ask your dealer.)

- Installation and set-up service adjustments.

- Batteries.

- Damage from misuse or neglect.

- Products which have been modified or incorporated into other products.

- Products purchased or serviced outside the USA.

- Acts of nature, such as but not limited to lightning damage.

#### How state law relates to this warranty:

- This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

#### If you purchased your product outside the USA:

- This warranty does not apply. Contact your dealer for warranty information.

FCC NUMBER IS LOCATED ON THE CABINET BOTTOM  
REN NUMBER IS LOCATED ON THE CABINET BOTTOM

